

Unit 2, 36 Liverpool St Ingleburn NSW 2565 T: 1300 459 327 www.outbackclotheslines.com.au

INSTALLATION INSTRUCTIONS - STUDIO LINE



Assembly:

- Assemble the Pivot Arm as per Figure 1. Do not over tighten the bolts.
- *Position the assembly on the wall at* the desired height
- Drill through the upper hole through the bracket using a 10mm masonry drill, insert the anchor through the bracket (Figure 2). Insert screw, and tighten.
- Level the assembly using a spirit level, drill remaining 3 holes and insert the

anchors and screws, and tighten.

- Insert spreader bars into the pivot arm assembly and retain with the spring buttons
- Bi
 sł
 Ri
 in
 Spreader Bar


Tools Required:

- Masonry Drill with 10mm Masonry bit
- Scissors, pliers or knife (to trim cord)
- Spirit Level

Figure 1 – Rear Assembly.

• 13mm Spanner or Socket and Wrench

Figure 2 – Insert goes through the bracket.



Feeding the cord:




Figure 5 – Feeding the cord

• Unroll the cord.

TIP: Always keep hold of the loose ends as this will prevent tangles.

- Feed one end down the hole closest to the wall allowing approx. 300mm for tying.
- Tie off as shown in the Figs 6 and 7.
- Feed the cord through the remaining holes as shown in Fig 5.
- To tension the cord, hold the free end tightly. Starting at the line closest to the wall, pull down firmly on the middle of the cord. Repeat the process on the next cord, working your way outwards removing any slack. Repeat the process until there is sufficient tension in the cord.
- Tie the loose end as shown in Figs 6 and 7. Trim the ends of the cord, leaving 100mm to be fed through the hole as shown in Fig 7.




Figure 7 – Tying off

Warranty Details

City Living Clotheslines undertake the following guarantee for its manufactured products;

- *Replacement of cord for a period of one (1) year from date of purchase.
- *Replacement of any other component of the clothes line for a period of ten (10) years from the date of purchase.
- This Guarantee is conditional as follows;
- *Failure is due to faulty workmanship or faulty material, allowing for fair wear and tear.
- *No evidence of misuse or maladjustment by the owner or any person using or repairing the product with or without the owner's consent.

*No cost will be borne by City Living Clotheslines for freight, postage, in-situ dismantling, replacement, re-assembling and adjustment of the product. *Any malfunction of the product must be promptly reported to City Living Clotheslines for immediate attention to prevent further damage. When a user-generated

problem is attended to by service Staff a service fee may be applicable.

This Guarantee exceeds and does not preclude any rights assured by the Trade Practices Act and any other State and Territory Laws.